

Key no.	Part no.	Description	q'ty	Key no.	Part no.	Description	q'ty
101	4512.869	Front Panel	1	202B	4512.879	Motor Gasket	1
102	4512.881	Rear Panel	1	203	4512.880	Power Cord	1
103	4512.890	Top Cover	1	204	4512.895	Compressor Capacitor	1
104	4512.865	Filter	1	205	4520.107	Main P.C. Board	1
105	4512.894	Water Tank	1	206	4520.108	Indicator P.C.Board	1
106	4512.851	Air Deflector	1	207	4512.734	Magnet	1
107	4512.870	Handle	1	208	4512.737	Magnetic Switch	1
108	4512.860	Cover For Light Indicator	1	209	4512.884	Humidity Sensor	1
109	4512.893	Water Level Display	1	210	4520.109	Copper Temperature Sensor Wire	1
110	4512.853	Bottom Base	1	214	4520.110	Pcb For Light Indicator	1
111	4520.100	Air Outlet	1	215	4520.011	R290 Sensor Wire (With Copper Head)	1
112	4512.872	Left Mat For Top Cover	1	216	4520.010	Sensor Tube (With Copper Head)	1
113	4512.883	Right Mat For Top Cover	1	301	4512.876	Metal Clip For Earthing Wire	1
114	4512.891	Top Cover For Main P.C. Board	1	302	4512.896	Castors	4
115	4512.854	Bottom Cover For Main P.C. Board	1	401	4512.859	Cool & Heat Exchanger	1
116	4512.864	Fan Blade	1	402	4512.861	Discharging Tube	1
117	4512.756	Bottom Cover For Sensor	1	403	4512.886	Suction Tube	1
119	4512.897	Float	1	404	4512.720	Suction Tube For Evaporator	1
120	4512.888	Supporter For Wires Fixing	1	405	4512.862	Discharging Tube For Condensor	1
122	4520.101	Rubber Plug	4	406	4512.746	Refrigerant Charging Tube	1
122A	4520.102	Rubber Plug A	2	407	4512.863	Dryer	1
126	4520.103	Capacitor Protecting Box (Up)	1	408	4520.114	Capillary	1
127	4520.104	Capacitor Protecting Box (Down)	1	409	4512.711	Sheath For Capillary	1
128	4520.105	Safety Box For Motor Capacitor-Down	1	410	4512.701	Thermal Sheath	1
129	4520.106	Safety Box For Motor Capacitor-Up	1	501	4512.867	Foam For Water Resist	1
201	N/A	Compressor	1	809	4512.850	Active Carbon Filter	1
202	4512.899	Motor	1	810	4520.113	Name Plate For Control Panel	1
202A	4512.878	Motor Capacitor	1				

N/A = Parts not available